

The vacuum mount kit is an optional console mounting assembly for use with Micro-Trak Consoles.

Installation

When installing your console, make sure you select a good mounting location. The console must be mounted in an area that is convenient for the operator, is easily accessible, and does not obstruct the view of the field or the road. It must also be installed in an area that is free of excessive cables and heat.

The suction cup will adhere to almost any clean, non-porous surface. It may be mounted onto the glass on the vehicle or any flat metal surface on the implement frame. **Important: Please remove RED protective cap before attempting to install the Vacuum Mount.**

1. To install the "U" Bracket on top of the suction cup, match the center hole to the corresponding stud on the suction cup, and fasten with the provided lock nut. **NOTE: If center hole is not provided drill the corresponding hole using a 1/4" drill bit.**
2. Make sure the plate is positioned so that the suction push button is free to operate. *See Illustration to the right.*
3. After selecting the best possible installation location, prepare the area for the suction cup mount. The area should be clean and completely dry. Place the suction cup firmly against the mounting surface and press the suction push button repeatedly until the red line disappears.
4. Place the console into the console mount brackets as illustrated in the console's installation and operator's manual.

Mounting Hardware (Not Shown)

- Whiz Lock Nuts (2)

